

105mm



# Pet Clippers

Model: PC18




User Manual  
ON-D201

140mm

## Safety Warnings

- Read Before Use:** Before using the clippers, read all safety and operating instructions.
- Electrical Safety:** Ensure that the voltage indicated on the rating label matches your electrical outlet. Do not immerse the appliance in water or any other liquids to avoid electric shock.  
**WARNING:** Keep the appliance dry.
- Supervision:** This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Regular Checks:** Periodically check the clippers for damage. If the appliance or power cord shows any sign of damage, do not use it. Contact the service center for repair or replacement.
- Regular Maintenance:** Disconnect the clippers from the power source before cleaning, changing accessories, or performing any maintenance. Keep the blades clean and well-oiled to avoid overheating and ensure optimal performance. Replace blades as needed.  
**WARNING:** Cutting blades may become hot after prolonged use.
- Storage:** After use, unplug and store the clipper in a dry place, away from pets and children.
- Handling:** Avoid touching the blades directly with your fingers. Always switch off the appliance when not in active use.
- Use for Intended Purpose:** These clippers are designed for trimming pet hair only. Do not use them for any other purpose.
- Disposal:** Dispose of the clipper and its accessories according to local regulations for electronic waste.


## Package List



## Specifications


Working Voltage	3.7V
Battery	2000mAh
Charging Time	3h
Working Time	4h
Input	5V ± 1A

## How to Use Guide Comb



This pet clipper comes with guide combs of 3/6/10/13/16/19mm, allowing 6-level adjustment of hair trimming length.

- Decide the Length:** Figure out the length you want for your pet's hair.
- Pick the Right Comb:** Select the corresponding guide comb.
- Installation and Removal of the Guide Comb**



- Installation:** Like the picture, align with the cutter head and push the guide comb downward until it clicks into place. (Ensure the guide comb is securely attached and does not wobble).
- Removal:** Push the bottom of the guide comb upward by hand and then remove it.

## Product Use

- Turn On/Off:** Push and twist the side switch for the pet clipper. Upward to turn on, downward to turn off.
- Power On:** The screen will display the battery indicator and oil drip reminder, oil drip reminder flashes for 5 seconds and then stop.
- Suggestion:** After use, it is recommended to clean the hair of the blade and give the blade oil drip maintenance.

## Cleaning & Maintenance

### How to disassemble/clean the blade

- Clean the blade with a cleaning brush.



- Disassemble the blade as shown in the picture, push the blade with your finger, the blade pops out, remove the blade.



### Installation the blade head:

- Align the bottom of the blade with the slots.
- Gently press the blade to secure it in place.




### Blade Maintenance:

Before or after use, drop some oil on the tip position of the blade to maintain the blade. (Oil included)



## Charging Instructions

- Charging:** Connect the original charging cable or Type C port charging cable to the adapter and plug in the pet clipper.



- Charging Process:** The power increases from 0-100%, and charging to 100% means the pet clipper is full. When charging, the power and charging symbols flash at the same time.



## Failure

Cause of Failure	Troubleshooting
Product Heating During Use	It is normal for the product to warm up during operation.
Product Not Working	Please ensure the device is fully charged. If charging does not work, kindly contact customer support.
Debris on the Blade	Clean the debris from the blade using a cleaning brush and water. After cleaning, apply oil to the blade. If the problem persists, please contact <a href="mailto:support@oneisall.com">support@oneisall.com</a>
Charging Issues	Avoid charging in very hot or cold environments. If the product still doesn't charge, contact customer service.
Optimal Charging Temperature	Please charge the product in an environment between 41°F and 104°F (5°C and 40°C).

## Warranty Information

Oneisall offers a standard 2-year warranty. If you have any issues with your Oneisall product, please do not hesitate to contact us. Be sure to include your proof of purchase, model number, and any relevant photos or videos in your message to expedite the process. Our Oneisall support team is available 7 days a week and will respond to your inquiry within 24 hours. Thank you for choosing Oneisall.

Please note that the Oneisall warranty does not apply to used products or purchases made from unauthorized sellers. It's important to be aware that the warranty also does not cover consumable parts such as blades, guards, filters, brushes, and similar items. These parts may require regular replacement or maintenance.

- ✉ [support@oneisall.com](mailto:support@oneisall.com)
- ☎ +1877-522-8578 (US) **Mon-Fri** 8am-5pm (PST)
- 🌐 [www.oneisall.com](http://www.oneisall.com)



@Oneisall Official

## GPSR Product Information

**UK REP** Name: APEX CE SPECIALISTS LIMITED  
Add: 6f East Union Street, Manchester, England, M16 9AE  
Contact: Wells  
Tel: +441618371080  
E-Mail: [info@apex-ce.com](mailto:info@apex-ce.com)

**EC REP** Name: Apex CE Specialists GmbH  
Add: Grafenberger Allee 277-287, 40237 Düsseldorf, DE  
Contact Person: Wells Yan  
Tel: +353212066339  
E-Mail: [info@apex-ce.de](mailto:info@apex-ce.de)

**GPSR-Manufacturer info:**  
Business Name: Shenzhenbenfendianzishangwuyouxiangongsi  
Manufacturer's address: CN, 518000, Guangdong Sheng, Shenzhen, Longhua District, Minxin Community Bishui Longting Building 6 Unit, 7B  
Tel: +86 185 6587 6424  
E-Mail: [topservice4u@hotmail.com](mailto:topservice4u@hotmail.com)

Product Name: Pet Clipper  
Brand: Oneisall  
Product Model: PC18  
Rated Voltage: 3.7V  
Input: 5V ± 1A

## FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
1. This device may not cause harmful interference, and  
2. This device must accept any interference received, including interference that may cause undesired operation.



Made in China

PC18 说明书设计文件 -V1 版

尺寸: 105\*140mm

材质: 128g 双铜 + 哑油

印刷: PANTONE 2018C +K

装订方式: 折页