


oneisall
TRANSFORM HOW YOU PET

Cozy SE 2 Smart Grooming Vacuum

Model: PG08



User Manual

Safety Warning

Please read all safety and operating instructions carefully before use.

- **Read Before Use:** Before using the pet hair vacuum, read all safety and operating instructions.
- **Supervision:** This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved, Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- **Cord Management:** If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- This device is not suitable for children under 8 years old and individuals with limited physical, sensory, or mental capabilities. Children must not perform cleaning and user maintenance without supervision.
- For safe operation, please use exclusively with the provided power cable. If the power cable is damaged, it must be replaced by the manufacturer or the service agent.
- Please ensure it is unplugged from the outlet before cleaning or maintaining the device. Unplug the power cord before replacing parts or performing maintenance.
- Do not use or store the device outside or in wet areas.
- Please ensure your hands are dry before operating or unplugging the power cord.
- This device is only for vacuum clean. Do not use for sucking up water.
- Do not inhale flammable or combustible liquids such as gasoline;
- Do not use the device in environments near flammable or combustible gases.
- Do not use while smoking or in proximity to other high-temperature items (matches, hot ashes, etc.).
- Do not insert objects into openings or block them.
- Please check the hose regularly ; Do not use it if it's damaged.
- Please keep the dust cup and filter clean; dirty filters can cause malfunctions and accidents.
- Please make sure the filter is correctly installed.
- Do not clean device the by immersing in water.
- Do not disassemble the product; incorrect assembly methods may lead to electric shock or fire.
- **Troubleshooting**
- The device will stop operating if it overheats, please stop using it immediately. If the intake is blocked, please stop using it immediately. Remove the dust cup, clean the intake and filter, and turn it on again
- IF there is an odor during the first use, it will dissipate over time, but if a burning smell persists, stop using the product immediately. If you have any questions, please feel free to contact our customer support at: support@oneisall.com

Use Precautions

Package List	01
Specifications	02
What to Do if My Pet Gets Nervous?	03
Product Overview	04
Getting Ready to Use	05
Using Different Accessories	06
Cleaning and Maintenance	09
Troubleshooting	11
Contact Us	12
GPSR Product Information	13
FCC Warning	14
IC Caution	14



Oneisall support



Tutorial Video


Package List




Vacuum Machine x1



Guide comb x 6 (3/6/9/12/15/18)



Hose x1




Pet Clipper x1



Pet Paw trimmer x1



Pet Nail Grinder x1



Grooming Brush x1



Deshedding
Brush x1



CreviceTool x1



Oil x1



Brush x1

Specifications

Pet Grooming vacuum:

Model	PG08
Input Voltage	US: 120V~60Hz / UK&EU: 220~240V~50Hz
Rated Power	400W
Hose Length	1.5m
Dust bin capacity	2L
Product Size	270*127*215mm


Pet Clippers

Input Voltage:	DC 5V = 1A
Rated Power:	5W
Charging Time:	About 3h
Working Time:	About 2h
Battery Capacity:	1400mAh


What to Do if My Pet Gets Nervous?

If your pet is nervous about the noise, you may need to let him get used to the machine at first.


1. Let your pet hear the sound of the machine.



2. Treat your pet with snack.




3. Start to use the vacuum. If your pet still get nervous, try to repeat 1-2 to let him know that this machine would not do harm to him.



Product Overview


1. Dust bin lifted upward and removed

To empty the dust bin: Lift the dust bin upward and remove it from the main unit.




2. On/off button

To turn the device on/off: Press the on/off button.




3. Gear adjustment button

To adjust the gear: Press the gear adjustment button to select the desired gear level.



4. Hose connection

To connect the hose: Attach the hose to the hose connection port.




5. Connection to power supply

To connect the device to power: Plug the power cord into the power outlet.


Getting Ready to Use

1. Install the Dust Bin

Tip: If the device has no suction or is very noisy, reinstall the dust bin.




2. Connect Accessories to the Vacuum Cleaner via the hose.



3. Plug the Power Cord into an Electrical Outlet.


4. Turn on the device by pressing the switch button.

5. Select the Cleaning Modes.



Tip: There are three cleaning modes: Gentle, Middle, and Powerful Mode. For the first use, choose the Gentle mode to help your pet get used to the noise gradually.


6. Groom Your Pet.



Using Different Accessories


Grooming Brush:

For cleaning and brushing loose hair to make your pet's fur healthier, shinier, and softer.




Deshedding Brush:

For removing long and excess dense fur from your pet.



Pet Clipper:

For trimming your pet's hair without leaving any hair behind. The machine will suck up the trimmed hair during the process!



Tips:

- ① Install the blade as required, otherwise the clipper will not work properly.
- ② When the red light on the clipper flashes, charge it using the included charging cable.
- ③ Pay attention to the cutting direction and position during trimming. Do not apply excessive force, as this may cause skin irritation to your pet.

Guide Comb (to be used with the clipper) Tips:

1. Choose the appropriate guide comb based on the desired length of your pet's fur.
2. The guide combs (3mm/6mm/9mm/12mm/15mm/18mm) are suitable for different fur lengths.



3mm (1/8")



6mm (1/4")



9mm (3/8")



12mm (1/2")



15mm (5/8")




18mm (3/4")

Illustrations for installing the guide comb and attaching/detaching the blade (use pictures to show).

Install the guide comb




Remove the guide comb



Pet Paw Trimmer:

For trimming excess hair on your pet's paws, eyes, ears, and rear end.




⚠ Tips:

Pay attention to the blade position and avoid using too much force, as this may cause skin irritation.

Pet Nail Grinder:

For trimming your pet's nails.



⚠ Tips:

Be careful of the soft parts of your pet's skin and avoid using too much force to prevent skin irritation.

Cleaning and Maintenance

1. Cleaning the Dust Bin

- ① Lift the dust bin upward and remove it.
- ② Open the dust bin and pour out the hairs.
- ③ Assemble the dust bin according to the direction of the arrow, and click it.



⚠ Tips:


If the removed dust bin is cleaned with water or wet cloth, make sure the dust bin is completely dry before installing, otherwise the motor will be damaged; Please make sure the dust bin is lightly spun, if it falls off, it will be easily damaged;

If you have any questions about the dust bin, please contact us through Amazon or email: support@oneisall.com

2. Clean the Clippers



- ① Rotate the upper part of the clippers;
- ② Sweep out and clean the debris from the blade and the electric push clipper;
- ③ Drizzle oil on the blades;



3. Cleaning the Hippo and Filter Pads

- ① Remove the dust bin and take out the seepa and sponge filter;
- ② Gently pat or clean with a brush, do not rinse with water;
- ③ Install the Haipia and also buy it filter back into the machine;



The product is equipped with a voltage protection device. If you hear a “ticking” sound and flashing when you press the switch, this means that the machine voltage is not consistent. Please check your voltage. If you have any questions, please feel free to contact our customer support at: support@oneisall.com

Troubleshooting

Problems	Possible Causes	Solutions
Machine Will Not Turn On	Switch has not been turned on right	Check the plug.
	The switch is not turned on.	Press the switch button to turn it on.
Weak Suction	The hose is clogged.	Clean the hose.
	The dust bin is too full.	Empty the dust bin.
	The filter is dirty.	Clean the filter.
	The dust bin is not properly installed.	Reinstall the dust bin and ensure it clicks into place, indicating proper installation.
Pet Clipper Heats Up During Use	There are debris inside the clipper.	Remove the blade, clean it, and apply oil.
Damaged Hose	Accidental damage.	Store the hose properly after use.

- If the above solutions do not solve the problem, please stop using the product, and contact our customer support: support@oneisall.com

Contact Us

WE ARE READY TO HELP

Oneisall provides a standard 2-year warranty. If you encounter any issues with your Oneisall product, please reach out to us. To help us assist you more efficiently, include your order number, model number, and any relevant photos or videos with your message. Our dedicated Oneisall support team is available 7 days a week and will respond to your inquiry within 24 hours. Thank you for choosing Oneisall.

Please note that the Oneisall warranty does not apply to used products or purchases made from unauthorized sellers. It's important to be aware that the warranty also does not cover consumable parts such as blades, guards, filters, brushes, and similar items. These parts may require regular replacement or maintenance.

- ✉ support@oneisall.com
- 📞 +1 877-522-8578 (US) Mon-Fri 8am-5pm (PST)
- 🌐 www.oneisall.com



Oneisall support



@Oneisall Official

GPSR Product Information



Name: Apex CE Specialists GmbH
Add: Grafenberger Allee 277-287,40237 Düsseldorf,DE
Contact Person: Wells Yan
Tel: +353212066339
E-Mail: Info@apex-ce.de



Name: APEX CE SPECIALISTS LIMITED
Add: 6f East Union Street, Manchester, England, M16 9AE
Contact: Wells
Tel: +441616371080
E-Mail: Info@apex-ce.com

GPSR-Manufacturer Info:

Business Name: Shenzhenbenfendianzishangwuyouxiangongsi
Manufacturer's Address: CN, 518000, GuangDong Sheng, Shenzhen,
Longhua District, Minxin Community Bishui Longting Building 6 Unit, 7B
Tel: +86 185 6587 6424
E-Mail: topservice4u@hotmail.com

Product Name: Cozy SE 2 Smart Grooming Vacuum
Brand: Oneisall
Product Model: PG08
Rated Voltage: US: 120V~60Hz / UK&EU: 220~240V~50Hz



Made in China

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

IC Caution:

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

1. This device may not cause interference; and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

1. l'appareil ne doit pas produire de brouillage, et
2. l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.



Any problems you have, please contact us :
support@oneisall.com



Oneisall support



Tutorial Video