


Pet Clippers and Paw Trimmer

Model: X2/C61



Any problems you have, please contact us:
support@oneisall.com

Safety Instructions

1. **Read Before Use:** Before using the clippers, read all safety and operating instructions.

2. **Electrical Safety:** Ensure that the voltage indicated on the rating label matches your electrical outlet. Do not immerse the appliance in water or any other liquids to avoid electric shock.

WARNING: Keep the appliance dry.

3. **Supervision:** This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

4. **Regular Checks:** Periodically check the clippers for damage. If the appliance or power cord shows any sign of damage, do not use it. Contact the service center for repair or replacement.

5. **Regular Maintenance:** Disconnect the clippers from the power source before cleaning, changing accessories, or performing any maintenance. Keep the blades clean and well-oiled to avoid overheating and ensure optimal performance. Replace blades as needed.

WARNING : Cutting blades may become hot after prolonged use.



6. **Storage:** After use, unplug and store the clipper in a dry place, away from pets and children.

7. **Handling:** Avoid touching the blades directly with your fingers. Always switch off the appliance when not in active use.

8. Use for Intended Purpose: These clippers are designed for trimming pet hair only. Do not use them for any other purpose.

9. **Disposal:** Dispose of the clipper and its accessories according to local regulations for electronic waste.

Each Part Name



2000mA high performance lithium battery

Professional Pet Clipper	Motor	Operating voltage:3.7V
		Centering material:anti-wear brass
	Battery	high-performance environment-friendly battery
		Charging time:about 3H
		Operating time with full charge:about 240 min

Specific Adapter	Input: 110V - 240V50/60Hz
	Output:DC 5V === 1 A

LCD

1>Charging status indicator

Remaining Battery performance	Battery indicator		20%	40%	60%	80%	100%
< 20%	ON	Flashing light	OFF	OFF	OFF	OFF	OFF
< 40%	ON	ON	Flashing light	OFF	OFF	OFF	OFF
< 65%	ON	ON	ON	Flashing light	OFF	OFF	OFF
< 80%	ON	ON	ON	ON	Flashing light	OFF	OFF
< 100%	ON	ON	ON	ON	ON	ON	ON


2>Operating status display

Remaining Battery performance	Battery indicator		20%	40%	60%	80%	100%
<100%	OFF	ON	ON	ON	ON	ON	Flashing light
< 80%	OFF	ON	ON	ON	Flashing light	OFF	OFF
< 60%	OFF	ON	ON	Flashing light	OFF	OFF	OFF
< 40%	OFF	ON	Flashing light	OFF	OFF	OFF	OFF
< 20%	OFF	Flashing light	OFF	OFF	OFF	OFF	OFF
< 5%	Flashing light	OFF	OFF	OFF	OFF	OFF	OFF


Fixed Length Function

- A:** Limited comb function trim for crew cut or the side hair
Special long(3,6,9,12,15,18mm)6 kinds of length adjustment to control the length of hair
- B:** Blade limit regulator: 5 kinds of length adjustment from 0.8mm-2.0mm


1. Determine the need hair length
2. Select the appropriate guide comb



3. Fine tune the blade



Moving the button left and right to adjust the blade (0.8mm-2.0mm)



Limit Comb installation:

Like the picture, hold both sides and push when butting the button positions. (Notes: the comb should not be loose or easy to fall off after being butted.)

Limit Comb dismantle:

Remove the butted positions with hands on its both sides and then remove the comb.


Blade Removal & Installation

Blade Removal




- Like the picture, press down the moving blade with the thumb and then remove the blade.
- Please hold with the other hand to avoid the blade falling off.

Blade Installation



- Adjust the adjusting ring to 2.0mm before installing the blade



- Direct the blade(B) at the hair clipper's slot(A) and plug in




- Push the blade down until it clicks

Cleaning & Maintenance


Taper Blade Cleaning



1. Clear up the blade with cleaning brush.




2. The blade can be removed out for cleaning



The moving blade can be turned back, and then cleaning the hair between the moving blade and the fixed blade.

Taper Blade Maintenance



Before or after use, maintain the blade by dripping some oil on the red point places like the left picture. (oil included)

Precautions For Use




1. Please do not disassemble the product.



2. The hair clipper can not be washed. Please keep it away from wet conditions.




3. The product can only be cleaned by cloth with little water or mild soap solution.



4. Do not charge the product under environment above 40°C or 0 °C

- The product can produce little heat during using or charging, which is normal.
- Please remove the battery safely and return it to the specified places when the battery runs out. Never discard it casually.



Each Part Name



Specifications

Pet Paw Trimmer	Motor	Operating voltage: 3V
	Battery	Battery type: 600mAh
		Charge time: 2h
		Operating time: 2h
	Charge	USB connect with adapter 5V $\overline{=}$ 1A
		Power: 5W


Use the rechargeable mode



1. Insert the usb cable into the tail of clipper
2. 5V/USB connect with adapter
3. The charge light is on when in charging

Please charge in 2hrs for first use or unused for more than half year

Cleaning & Maintenance



Remove the blade counter clockwise rotate and pull out the blade.



1. Use a clean brush to clean the dirt and hairs around the blade.



2. The blade can be removed out for washing and cleaning.

Q&A

Q: Is it possible to trim pet ear hair and what is the noise decibel?

A1: Yes, it is very suitable for trimming ear hair and foot hair; the decibel is 55dB.

A2: It is recommended that sensitive areas such as the buttocks genitals, and around the eyes should only be cut short the hair and not shaved.

Q: Can this Small Pet Hair Trimmer be used on cats?

A: Yes, it can be used for both dogs and cats.

Q: Can this Small Pet Clippers shave pet body hair?

A1: The big clipper is only suitable for trimming the body hair of cats and dogs under 10 kg.

A2: The small paw trimmers are only suitable for pets'paws, ears, face and other small parts of hair, not suitable for pets trimming body hair.

Q: Is it recommended to shave all pet's foot hair? How much mm is recommended for trimming?

A: It is not recommended to shave all the pet's foot hair which is not good for pets. it is recommended to leave 0.2mm hair.

Q: Charging time and battery life.

A1: Charging for 2 hours, battery life is about 2hours

Q: Will the blade get hot?

A1: After the product has been working for 30 minutes, the temperature of the cutter head is about 36°C (96.8 °F), and the temperature is within the acceptable range of somato-sensory

Q: What is the service life of the cutter head?

Can the cutter head be replaced?

A1: The life of the blade depends on the frequency of use and the area of use. If you have any problems, such as blunt blades, you can contact our support team for help.

Q: What should i do if the battery cannot be charged or turned on?

Is there a warranty for the Small Pet Clippers ?

A1: Yes, our products have 2 years warranty. If you have any questions about this product, please feel free to contact us. The email is: support@oneisall.com

GPSR Product information

UK REP

Name: APEX CE SPECIALISTS LIMITED

Add: 6f East Union Street, Manchester, England, M16 9AE

Contact: Wells

Tel: +441616371080

E-Mail: Info@apex-ce.com

EC REP

Name : Apex CE Specialists GmbH

Add : Grafenberger Allee 277-287,40237 Düsseldorf,DE

Contact Person: Wells Yan

Tel: +353212066339

E-Mail: Info@apex-ce.de

GPSR-Manufacturer info:

Business Name: Shenzhenbenfendianzishangwuyouxiangongsi

Manufacturer's Address: CN, 518000, GuangDong Sheng, Shenzhen, Longhua District, Minxin Community Bishui Longting Building 6 Unit, 7B

Tel: +86 185 6587 6424

E-Mail: topservice4u@hotmail.com

Product Name: Pet Clippers and Paw Trimmer

Brand: Oneisall

Product Model: X2/C61

Input: 5V = 1A



Made in China

Contact Us

WE ARE READY TO HELP

oneisall offers a standard 2-year warranty. If you have any issues with your oneisall product, please do not hesitate to contact us. Be sure to include your proof of purchase, model number, and any relevant photos or videos in your message to expedite the process. Our oneisall support team is available 7 days a week and will respond to your inquiry within 24 hours. Thank you for choosing oneisall.

Please note that the oneisall warranty does not apply to used products or purchases made from unauthorized sellers. It's important to be aware that the warranty also does not cover consumable parts such as blades, guards, filters, brushes, and similar items. These parts may require regular replacement or maintenance.

✉ support@oneisall.com

☎ +1 877-522-8578 (US) Mon-Fri 8am-5pm(PST)

🌐 Web: www.oneisall.com



@Oneisall Official

oneisall
TRANSFORM HOW YOU PET

Any problems you have, please contact us :
support@oneisall.com



Scan the QR-Code to get the
product installation video and join us to get
more prize

ON-SETD1